OPERATION

Hand Shower Adjustable Mount

Pinch Release Button and move Hand Shower Adjustable Mount up or down.

⚠ CAUTION!

Care should be taken when moving the Hand Shower Adjustable Mount up or down.

Be sure that the Slide Bar is free of any soap, shampoo or cleaning agent as these substances could cause the Hand Shower Adjustable Mount to lose its grip on the bar and slide down.



Adjustable Mount Pivot

Release Button does NOT need to be pressed for pivoting.

TIP:

Razor Hanger can be easily removed and repositioned to any desired location on the Slide Bar.

Hand Shower Spray Selections

Turn spray face to select any 1 of 5 desired sprays.

TIP:

Spray face can be turned in either direction however there is a stop point.

Slide Bar Pivot

Slide Bar is designed to pivot forward and backward.

Diverter Valve

Turn the Diverter Handle to route water flow to the Rain Shower OR to the Hand Shower

TIP:

When switching the flow from the Rain Shower to the Hand Shower, all of the water will not drain from the Rain Shower immediately. Water will continue to drip from the Rain Shower for a minute or two.



Activate Fog Proof Mirror Feature - Warm Mirror Back Side

1. Pivot Mirror to reveal copper covered **back side**.
2. Spray Mirror back side with the Hand Shower for 5 seconds.
3. Pivot Mirror to reveal front side and enjoy a fog free view.



TIP:

The shower water used to heat the mirror does not need to be warmer than the water temperature you will be showering in.

Depending on how big the difference is between the air and shower water temperature, it may require more or less time to fully heat the mirror for proper fog proofing.

Questions? Assistance?

Do you have questions about the installation or functions of this product?

1-800-776-6364
M-F 8am to 5pm PST

ShowerTek, Inc.

www.showertek.com