⚠ CAUTION

⚠ Slide Bar

If soap, shampoo or any shower cleaning product is applied to the Slide Bar, the Hand Shower Adjustable Mount may lose its grip and slide to the bottom of the bar. To restore the grip of the Hand Shower Adjustable Mount on the bar, the bar should be washed totally clean with plain water.

⚠ Rain Shower Showerhead & Swing Arm

Do not hang anything from the Swing Arm and Rain Shower Showerhead. Always be sure that the bottom Wing Nut on the Swing Arm is sufficiently tight after adjusting the position of the Swing Arm. Periodically check the Wing Nuts to make sure they are tight and that the Swing Arm is secure.

⚠ Glass Mirror

While the glass mirror does have a safety backing, care should always be taken to keep it safe and protected. Should you ever break the mirror, use of the product should be discontinued immediately. Replacement mirrors can be obtained from www.showertek.com or by calling 1-800-776-6364.

CLEANING

Surfaces

Do not use harsh chemicals, abrasive cleaners or textured sponges / cloths to clean this product. This may damage the surface finish and void the warranty. Most popular shower cleaning products are suitable for cleaning the product surfaces of water marks, mineral deposits and soap scum. Always test the cleaning product on a hidden part of the product before full use. Always rinse all product surfaces clean of any cleaning product residue with clear water. Towel dry for a spot free shine.

Mirror

ONLY glass approved cleaners should be used on the mirror. To avoid water spotting, the mirror should be towel dried after each use. If water spotting does build up on the mirror over time, a commercial shower mineral deposit cleaner approved for glass can be used to resore the glass surface.

Mineral Build-up

Due to hard water mineral build-up, water flow through the Rain Shower and Hand Shower spray nozzles may over time become restricted. The nozzles are easily cleaned by flexing the rubber spray jets which will break up the mineral deposits and restore full water flow through them. If mineral build-up is excessive, the Hand Shower or Rain Shower spray nozzles can be soaked in household vinegar or a popular commercial shower cleaning product.

Filter Washers

Two filter washers are used in this product - one in the Rain Shower plumbing connection and one in the Hand Shower plumbing connection. These filter washers should be inspected and cleaned periodically, removing any mineral deposits or other matter. If water flow from either showerhead ever appears to be less than normal, the respective filter washer should be inspected and scrubbed clean to help restore proper water flow. See page 2 for exact Filter Washer locations.

TROUBLESHOOTING GUIDE

PROBLEM	*SOLUTION*
There is a leak at a screwed-together connection.	Is the connection screwed together tight enough? If you have weak hand strength, you may need to use tools to get the connection tight enough. If the connection is tight and still leaking, you will need to wrap the screw threads at the connection with plumbing tape. Plumbing tape has been included.

TROUBLESHOOTING GUIDE Con't.

PROBLEM	*SOLUTION*
The shower spray is not as strong as it used to be.	Minerals and impurities in your water may over time become deposited on the two filter washers used in this product and on the rubber spray nozzles where water exits the showerheads. These deposits will reduce water flow. The filter washers should be exposed and scrubbed clean. The rubber nozzles should be flexed or rubbed to break up any deposits. See page 2 for filter washer locations.
The mirror is not staying fog free.	The mirror will only become and stay fog free if the temperature of the mirror is warmed to the same temperature as your shower water. Try spraying the back side of the mirror for a longer period of time. As a rule, the larger the difference between the air temperature and your shower water temperature, the longer you will need to spray the back of the mirror - so that it becomes the same temperature as the shower water.
The glass mirror is broken.	Not to worry! Your luck has not run out! A replacement mirror can be ordered from ShowerTek, Inc. - www.showertek.com or 800-776-6364. The entire Mirror/ Adjustable Mount assembly has been designed to be replaceable. It is easy to remove and install the new parts. Use of the product should be suspended until the mirror can be replaced.
What does my warranty cover?	Your warranty protects you for the period of **one year after purchase** from being responsible for any defects in your product created at the time it was manufactured. It does not protect your product from normal wear and tear created during use. It also does not protect your product from any damage caused by you.
Why should I register my product?	Registering your product helps us to guarantee your warranty service. Your registration can be completed quickly on the web: www.showertek.com.
I need warranty service.	Please see the separate Warranty Card for instructions. Or go to www.showertek.com.

Due to continuing improvements, your product may differ slightly from the product photos shown in this instruction document.

Questions? Assistance?

Do you have questions about the installation or functions of this product?

1-800-776-6364
M-F 8am to 5pm PST

ShowerTek, Inc.

www.showertek.com

page 6 page 6 page 6 page 6 page 6 page 6 page 6 page 6 page 6 page 6 page 6 page 6 page 6